

Nosler® Rifles

How Do I Troubleshoot My Rifle?

1. Clean your barrel
2. Make sure action screws are tight
3. Make sure scope bases and rings are tight
4. Make sure scope is tracking properly

If these steps to not produce desired results please see: <http://www.nosler.com/service-returns/>

Unique solution ID: #1072

Author: John Bullet

Last update: 2016-03-03 20:13